

## Economical Aerators 3,8 l/min; 1,9 l/min



<b>SLA 55A</b>	<b>06550</b>	Economical aerator 3,8 l/min for SLU 01N/02N, SLU 04H/HT, SLU 10, SLU 15, SLU 16, SLU 21/22, SLU 24D, SLU 25, SLU 34, SLU 35, SLU 36 and SLUN 06
<b>SLA 55B</b>	<b>06551</b>	Economical aerator 1,9 l/min for SLU 01N/02N, SLU 04H/HT, SLU 10, SLU 15, SLU 16, SLU 21/22, SLU 24D, SLU 25, SLU 34, SLU 35, SLU 36 and SLUN 06

- the key is not included, change is done by nut key (22 mm)



<b>SLA 56A</b>	<b>06560</b>	Economical aerator 3,8 l/min for SLU 09PTB, SLU 39, SLU 42K, SLU 43, SLU 43V, SLU 44, SLU 45/46, SLU 91N-92N and SLUN 04, SLUN 07, SLUN 50-53, SLUN 71/72, SLUN 80-83
<b>SLA 56B</b>	<b>06561</b>	Economical aerator 1,9 l/min for SLU 09PTB, SLU 39, SLU 42K, SLU 43, SLU 43V, SLU 44, SLU 45/46, SLU 91N-92N and SLUN 04, SLUN 07, SLUN 50-53, SLUN 71/72, SLUN 80-83

- the key is included



<b>SLA 57A</b>	<b>06570</b>	Economical aerator 3,8 l/min for SLU 41, SLU 54N, SLU 60, SLU 63, SLU 76, SLU 83, SLU 93
<b>SLA 57B</b>	<b>06571</b>	Economical aerator 1,9 l/min for SLU 41, SLU 54N, SLU 60, SLU 63, SLU 76, SLU 83, SLU 93

- the key is included